



Instructions:

1. Cut the telephone cable where you want to terminate the cable
2. Strip the telephone cable's jacket about 1" long, exposing the internal wires
3. Separate the wires inside and order them black, red, green, then yellow, while the RJ11 connector's tab is on the bottom
4. Insert the wires through the connector so they are sticking out the other end & the wedge of the connector is contacting the jacket of the cable
5. Insert the wired connector fully into the pass-through RJ11 slot of a crimping tool so that the wires at the end of the connector are sticking out
6. Squeeze the handles of the tool to crimp the connector and flush cut the ends of the wires

